



5 Port Pilot Operated Solenoid Valve

Rubber Seal, Plug-in/Non Plug-in

Series VFR2000



JIS Symbol



Standard Specifications

Valve specifications		Air	
Operating pressure range	2 position single/3 position	0.2 to 0.9 MPa	
	2 position double	0.1 to 0.9 MPa	
Ambient and fluid temperature		-10 to 50°C (No freezing. Refer to page 3-13-4.)	
Lubrication		Not required ⁽¹⁾	
Manual override		Non-locking push type	
Mounting orientation		Unrestricted	
Shock/Vibration resistance		300/50 m/s ² ⁽²⁾	
Enclosure		Dustproof	
Coil rated voltage		100, 200 VAC (50/60 Hz), 24 VDC	
Allowable voltage fluctuation		-15 to -10% of rated voltage	
Apparent power (AC) ⁽³⁾	Inrush	5.6 VA/50 Hz, 5.0 VA/60 Hz	
	Holding	3.4 VA (2.1 W)/50 Hz, 2.3 VA (1.5 W)/60 Hz	
Power consumption (DC) ⁽³⁾		1.8 W	
Electrical entry	Plug-in type	Conduit terminal	
	Non plug-in type	Grommet, Grommet terminal Conduit terminal, DIN terminal L plug connector, M plug connector	



Note 1) Use turbine oil Class 1 (ISO VG32), if lubricated. Note 2) Impact resistance: No malfunction occurred when it is tested with a drop tester in the axial direction and at the right angles to the main valve and armature in both energized and de-energized states every once for each condition. (Values at the initial period)

Vibration resistance: No malfunction occurred in a one-sweep test between 45 and 2000 Hz. Test was performed at both energized and de-energized states in the axial direction and at the right angles to the main valve and armature. (Values at the initial period)

Option Specifications

Pilot type	External pilot ^{Note)}
Manual override	Non-locking push type A (Extended), Locking type B (Tool required), Locking type C (Lever)
Coil rated voltage	110 to 120, 220, 240 VAC 50/60 Hz 12, 100 VDC
Porting specifications	Bottom ported
Option	With light/surge voltage suppressor



Note) Operating pressure: 0 to 0.9 MPa
Pilot pressure: 2 position single/3 position 0.2 to 0.9 MPa
2 position double 0.1 to 0.9 MPa

Model

Type of actuation	Model		Port size Rc	Flow characteristics ⁽¹⁾						Max. operating cycle ⁽²⁾ (Hz)	Response time ⁽³⁾ (ms)	Weight ⁽⁴⁾ (kg)	
	Plug-in	Non plug-in		1 → 4/2 (P → A/B)			4/2 → 5/3 (A/B → EA/EB)						
				C [dm ³ /(s·bar)]	b	Cv	C [dm ³ /(s·bar)]	b	Cv				
2 position	Single	VFR2100	VFR2110	1/8	2.5	0.18	0.58	3.0	0.27	0.70	10	20 or less	0.34 (0.32)
		VFR2200	VFR2210	1/4	2.8	0.24	0.62	3.0	0.27	0.70			
	Double	VFR2200	VFR2210	1/8	2.4	0.21	0.56	3.1	0.28	0.74	10	20 or less	0.42 (0.44)
		VFR2200	VFR2210	1/4	2.6	0.27	0.62	3.1	0.28	0.74			
3 position	Closed center	VFR2300	VFR2310	1/8	1.3	0.45	0.36	1.4	0.46	0.41	5	30 or less	0.43 (0.45)
		VFR2300	VFR2310	1/4	1.3	0.45	0.36	1.4	0.46	0.41			
	Exhaust center	VFR2400	VFR2410	1/8	0.79	0.53	0.24	3.1 [0.89]	0.24 [0.51]	0.74 [0.27]	5	30 or less	0.43 (0.45)
		VFR2400	VFR2410	1/4	0.79	0.53	0.24	3.1 [0.89]	0.24 [0.51]	0.74 [0.27]			
	Pressure center	VFR2500	VFR2510	1/8	2.8 [0.65]	0.24 [0.60]	0.68 [0.21]	0.89	0.53	0.27	5	30 or less	0.43 (0.45)
		VFR2500	VFR2510	1/4	3.2 [0.75]	0.26 [0.55]	0.73 [0.23]	0.89	0.53	0.27			




Note 1) []: Denotes the normal position.
 Note 2) Min. operating frequency is once in 30 days. (As per JIS B 8375)
 Note 3) Based on dynamic performance test, JIS B 8375-1981. (0.5 MPa, Coil temperature: 20°C, at rated voltage, without surge voltage suppressor)
 Note 4) For VFR2□00-□FZ-₀₂, (): VFR2□10-□DZ-₀₂

Series VFR2000

How to Order

Electrical entry

F: Plug-in type

Option

Nil	None
Z	With light/surge voltage suppressor

Piping (P, A, B, EA, EB port)

Nil	Side ported
B *	Bottom ported

* Option

Port size (P, A, B port)

Nil	Without sub-plate
01	1/8
02	1/4

EA, EB port: Rc 1/8

Thread type


Nil	Rc
F	G
N	NPT
T	NPTF

Plug-in VFR2 1 00 [] 5 F [] [] [] 01 []

Non plug-in VFR2 1 10 [] 1 E [] [] [] 02 []

Pilot valve manual override

Nil: Non-locking push type	A*: Non-locking push type A (Extended)	B*: Locking type B (Tool required)	C*: Locking type C (Lever)
----------------------------	--	------------------------------------	----------------------------



* Option


Option

Nil	None
Z	With light/surge voltage suppressor
S *	With surge voltage suppressor


* Indicator light is not available for grommet type. With surge voltage suppressor is available for grommet type only.

Electrical entry

G: Grommet	E: Grommet terminal	T: Conduit terminal	D, Y: DIN terminal
------------	---------------------	---------------------	--------------------



L: L plug connector	M: M plug connector
---------------------	---------------------



Symbol

1 2 position single (A/B) (EA/PP/EB)

2 2 position double (A/B) (EA/PP/EB)

3 3 position closed center (A/B) (EA/PP/EB)

4 3 position exhaust center (A/B) (EA/PP/EB)

5 3 position pressure center (A/B) (EA/PP/EB)

Pilot type

Nil	Internal pilot
R *	External pilot

* Option (External pilot is available only on sub-plate type.)

Coil rated voltage

1	100 VAC, 50/60 Hz
2	200 VAC, 50/60 Hz
3 *	110 V to 120 VAC, 50/60 Hz
4 *	220 VAC, 50/60 Hz
5	24 VDC
6 *	12 VDC
7 *	240 VAC, 50/60 Hz
9 *	Other

* Option

How to Order Pilot Valve Assembly

SF4 - 1 DZ [] - 60

Manual override

Nil	Non-locking push type
A *	Non-locking push type A (Extended)
B *	Locking type B (Tool required)
C *	Locking type C (Lever)

* Option

Coil rated voltage

1	100 VAC, 50/60 Hz
2	200 VAC, 50/60 Hz
3 *	110 to 120 VAC 50/60 Hz
4 *	220 VAC, 50/60 Hz
5	24 VDC
6 *	12 VDC
7 *	240 VAC, 50/60 Hz
9 *	Other

* Option


Electrical entry, Light/Surge voltage suppressor

Symbol	Electrical entry	Indicator light	With surge voltage suppressor	Body type	Symbol	Electrical entry	Indicator light	With surge voltage suppressor	Body type
F	Plug-in	—	—	Plug-in type	T	Conduit terminal	—	—	Non plug-in type
G	Grommet	—	—	Non plug-in type	TZ	Grommet terminal	●	●	
GS		—	●		E		L plug connector	—	
D	DIN terminal	With connector	—		LZ	L plug connector (Without connector)		●	
DZ		Without connector	—		LO		M plug connector	—	
DO	—	—	MO		M plug connector (Without connector)	●		●	
DOZ	—	—	MOZ			—	—		
Y	DIN terminal (DIN43650B)	With connector	—						
YZ		Without connector	—						
YO		—	—						
YOZ	—	—							

5 Port Pilot Operated Solenoid Valve Rubber Seal, Plug-in/Non Plug-in Series VFR2000

Use as a guide for selection.
Please confirm the actual conditions with SMC
Sizing Program.

Cylinder Speed Chart




- VK
- VZ
- VF
- VFR**
- VP4
- VZS
- VFS
- VS4
- VQ7
- EVS
- VFN

* It is when the cylinder is extending that is meter-out controlled by speed controller which is directly connected with cylinder, and its needle valve with being fully open.
 * The average velocity of the cylinder is what the stroke is divided by the total stroke time.
 * Load factor: ((Load weight x 9.8)/Theoretical force) x 100%
 Note) The Series CA1 has been changed to the Series CA2.

System Components

System	Solenoid valve	Speed controller	Silencer	Tube bore x Length
A	Series VFR2000 Rc 1/8	AS2000-01 (S = 2.5 mm ²)	AN110-01 (S = 35 mm ²)	T0425 x 1 m
B		AS3000-02 (S = 12 mm ²)	AN110-01 (S = 35 mm ²)	T0604 x 1 m
C		AS3000-02 (S = 12 mm ²)	AN110-01 (S = 35 mm ²)	T0806 x 1 m
D	Series VFR2000 Rc 1/4	AS4000-02 (S = 21 mm ²)	AN110-01 (S = 35 mm ²)	T1075 x 1 m
E		AS4000-02 (S = 21 mm ²)	AN110-01 (S = 35 mm ²)	T1209 x 1 m

How to Order Sub-plate Assembly




Series VFR2000

Construction


2 position single

2 position double

VFR21□0




VFR22□0




3 position closed center/exhaust center/pressure center



Closed center: VFR23□0



Exhaust center: VFR24□0



Pressure center: VFR25□0



This figure shows a closed center type.

Component Parts

No.	Description	Material	Note
①	Body	Aluminum die-casted	Platinum silver
②	Sub-plate	Aluminum die-casted	Platinum silver
③	Spool valve	Aluminum, NBR	
④	Adapter plate	Aluminum die-casted	Platinum silver
⑤	Adapter plate	Aluminum die-casted	Platinum silver
⑥	End plate	Resin	Black

No.	Description	Material	Note
⑦	Piston	Resin	
⑧	Piston	Resin	
⑨	Junction cover	Resin	
⑩	Light cover assembly	Resin	
⑪	Spool spring	Stainless steel	
⑫	Return spring	Stainless steel	


Replacement Parts

No.	Description	Material	Part no.		
			VFR21□0	VFR22□0	VFR23□0/24□0/25□0
⑬	Gasket	NBR	AXT624-20-2	AXT624-20-2	AXT624-20-2
⑭	Hexagon socket head screw	Steel	AXT624-26 (M3 x 31)	AXT624-26 (M3 x 31)	AXT624-26 (M3 x 31)
⑮	Pilot valve assembly	—	Refer to "How to Order Pilot Valve Assembly" on page 3-5-10.		
—	Sub-plate assembly	—	Refer to "How to Order Sub-plate Assembly" on page 3-5-11.		

5 Port Pilot Operated Solenoid Valve Rubber Seal, Plug-in/Non Plug-in Series VFR2000


Plug-in 2 position single/double, 3 position closed center/exhaust center/pressure center

2 position single: VFR2100-□F-⁰¹/₀₂




() : Rc 1/8

2 position double: VFR2200-□F-⁰¹/₀₂



* Other dimensions are the same as the single type.

3 position closed center: VFR2300-□F-⁰¹/₀₂
 3 position exhaust center: VFR2400-□F-⁰¹/₀₂
 3 position pressure center: VFR2500-□F-⁰¹/₀₂




* Other dimensions are the same as the single type.

- VK
- VZ
- VF
- VFR
- VP4
- VZS
- VFS
- VS4
- VQ7
- EVS
- VFN


Series VFR2000

Non Plug-in 2 position single


Grommet: VFR2110-□G-⁰¹₀₂




Grommet terminal: VFR2110-□E-⁰¹₀₂




Conduit terminal: VFR2110-□T-⁰¹₀₂




DIN terminal: VFR2110-□D-⁰¹₀₂



L plug connector: VFR2110-□L-⁰¹₀₂




M plug connector: VFR2110-□M-⁰¹₀₂



5 Port Pilot Operated Solenoid Valve Rubber Seal, Plug-in/Non Plug-in Series VFR2000


Non Plug-in 2 position double

Grommet: VFR2210-□G-⁰¹/₀₂




- VK
- VZ
- VF
- VFR**
- VP4
- VZS
- VFS
- VS4
- VQ7
- EVS
- VFN

Grommet terminal: VFR2210-□E-⁰¹/₀₂




* Other dimensions are the same as the grommet type.

Conduit terminal: VFR2210-□T-⁰¹/₀₂




* Other dimensions are the same as the grommet type.

DIN terminal: VFR2210-□^D_Y-⁰¹/₀₂




* [^D]: Type Y
* Other dimensions are the same as the grommet type.

L plug connector: VFR2210-□L-⁰¹/₀₂



* Other dimensions are the same as the grommet type.

M plug connector: VFR2210-□M-⁰¹/₀₂




* Other dimensions are the same as the grommet type.

Series VFR2000

Non Plug-in 3 position closed center/exhaust center/pressure center


Grommet

Closed center: VFR2310-□G-⁰¹/₀₂
 Exhaust center: VFR2410-□G-⁰¹/₀₂
 Pressure center: VFR2510-□G-⁰¹/₀₂



Grommet terminal


Closed center: VFR2310-□E-⁰¹/₀₂
 Exhaust center: VFR2410-□E-⁰¹/₀₂
 Pressure center: VFR2510-□E-⁰¹/₀₂



* Other dimensions are the same as the grommet type.

Conduit terminal


Closed center: VFR2310-□T-⁰¹/₀₂
 Exhaust center: VFR2410-□T-⁰¹/₀₂
 Pressure center: VFR2510-□T-⁰¹/₀₂



* Other dimensions are the same as the grommet type.

DIN terminal


Closed center: VFR2310-□D-⁰¹/₀₂
 Exhaust center: VFR2410-□D-⁰¹/₀₂
 Pressure center: VFR2510-□D-⁰¹/₀₂



* [] : Type Y
 * Other dimensions are the same as the grommet type.

L plug connector


Closed center: VFR2310-□L-⁰¹/₀₂
 Exhaust center: VFR2410-□L-⁰¹/₀₂
 Pressure center: VFR2510-□L-⁰¹/₀₂



* Other dimensions are the same as the grommet type.

M plug connector

Closed center: VFR2310-□M-⁰¹/₀₂
 Exhaust center: VFR2410-□M-⁰¹/₀₂
 Pressure center: VFR2510-□M-⁰¹/₀₂



* Other dimensions are the same as the grommet type.

Series VFR2000 Manifold Specifications

Manifold Specifications

Base model	Wiring	Porting specifications		Port size		Stations	Applicable valve model
		A, B port		P, EA, EB	A, B		
Plug-in type VV5FR2-01□	<ul style="list-style-type: none"> • With terminal block • With multi-connector • With D-sub connector 					2 to 15	VFR2□00-□F
						2 to 8	
Non plug-in type VV5FR2-10	<ul style="list-style-type: none"> • Grommet • Grommet terminal • Conduit terminal • DIN terminal • L plug connector • M plug connector 	Side/Bottom <small>(Note)</small>	1/4	1/8, 1/4 C6, C8	2 to 15	VFR2□10-□G VFR2□10-□E VFR2□10-□T VFR2□10-□D VFR2□10-□L VFR2□10-□M	

Note) Side ported and bottom ported cannot be taken at the same time.

How to Order Manifold Assembly

<Example> Plug-in type with terminal block (6 stations, one-piece junction cover)

VV5FR2-01T1-061-02 1 set (Manifold base part no.)
 *VFR2100-5FZ 3 sets (2 position single part no.)
 *VFR2200-5FZ 2 sets (2 position double part no.)
 *VVFS2000-10A 1 set (Blanking plate assembly part no.)
 ↳ The asterisk denotes the symbol for assembly. Prefix it to the part nos. of the solenoid valve, etc.

Valve arrangement is counted from the D side.
 When ordering, specify the part nos. in order from the 1st. station in the D side.
 When entry of part numbers becomes complicated, indicate on the manifold specification sheet.


<Example> Non plug-in type: 6 stations

VV5FR2-10-061-01 1 set (Manifold base part no.)
 *VFR2110-5D 5 sets (2 position single part no.)
 *VFR2410-5D 1 set (3 position exhaust part no.)
 *VVFS2000-R-01-2 1 set (Individual EXH spacer part no.)
 ↳ The asterisk denotes the symbol for assembly. Prefix it to the part nos. of the solenoid valve, etc.

Valve arrangement is counted from the D side.
 When ordering, specify the part nos. in order from the 1st. station in the D side.
 When entry of part numbers becomes complicated, indicate on the manifold specification sheet.

Plug-in Type: With Terminal Block

- Since lead wires of solenoid valve are connected with the terminals on upper surface of terminal block corresponding lead wires from power source can be wired at the bottom of terminal block.



VV5FR2 - 01T 1 - 08 1 - 02

Series VFR2000 Manifold

Plug-in type with terminal block

Junction cover

Nil	Individual junction cover
1	One-piece junction cover

Stations

02	2 stations
⋮	⋮
15	15 stations

Symbol

Symbol	Passage		Porting specification A, B
	P	EA, EB	
1	Common	Common	Side
2*	Common	Common	Bottom
3*	Common	Individual	Side
4*	Common	Individual	Bottom
5*	Individual	Common	Side
6*	Individual	Common	Bottom
7*	Individual	Individual	Side
8*	Individual	Individual	Bottom

* Option

Port size

Symbol	P, EA, EB	A, B *	
		1/8	1/4
01	1/4	1/8	1/4
02		1/8	1/4
C6		One-touch fitting for ø6	
C8		One-touch fitting for ø8	
M		Mixed	


* For bottom ported, 1/8 is only available.

Thread type

Nil	Rc
F	G
N	NPT
T	NPTF

Plug-in Type: With Multi-connector (For wiring specifications, refer to page 3-5-8.)

- Master connection of power and solenoid valves.
- Quick wiring permits ease of installation.



VV5FR2 - 01C D 1 - 05 1 - 01

Series VFR2000 Manifold

Plug-in type with multi-connector

Connector mounting direction

D	D side mounting
U	U side mounting

Junction cover

1	One-piece junction cover
---	--------------------------

Stations

02	2 stations
⋮	⋮
08	8 stations

* Max. 8 stations

Symbol

Symbol	Passage		Porting specification A, B
	P	EA, EB	
1	Common	Common	Side
2*	Common	Common	Bottom
3*	Common	Individual	Side
4*	Common	Individual	Bottom
5*	Individual	Common	Side
6*	Individual	Common	Bottom
7*	Individual	Individual	Side
8*	Individual	Individual	Bottom

* Option

Port size

Symbol	P, EA, EB	A, B *	
		1/8	1/4
01	1/4	1/8	1/4
02		1/8	1/4
C6		One-touch fitting for ø6	
C8		One-touch fitting for ø8	
M		Mixed	

* For bottom ported, 1/8 is only available.


Thread type

Nil	Rc
F	G
N	NPT
T	NPTF

Series VFR2000

Plug-in Type: With D-sub Connector (For wiring specifications, refer to page 3-5-8.)

- Wide range of interchangeability (D-sub connector (25P) conforming to MIL standard)
- Quick wiring permits easier installation.



VV5FR2 - 01F U 1 - 06 1 - 01

Series VFR2000 Manifold
Plug-in type
with D-sub connector

Connector mounting direction

D	D side mounting
U	U side mounting

Junction cover

1	One-piece junction cover
---	--------------------------

Stations

02	2 stations
⋮	⋮
08	8 stations

* Max. 8 stations

Symbol			Port size			Thread type		
Symbol	Passage		Porting specifications A, B	Symbol	P, EA, EB	A, B *	Nil	Rc
	P	EA, EB						
01				01		1/8	F	G
02				02		1/4	N	NPT
1	Common	Common	Side	C6	1/4	One-touch fitting for ø6	T	NPTF
2 *			Bottom					
3 *	Side							
4 *	Bottom							
5 *	Individual	Common	Side	C8		One-touch fitting for ø8		
6 *			Bottom					
7 *	Individual	Individual	Side	M		Mixed		
8 *			Bottom					


* For bottom ported, 1/8 is only available.

* Option

Note) P port or EA/EB port of symbol "3" to "8" can be individual port with block plate. Therefore, if using individual SUP spacer or individual EXH interface for individual port, its symbol is "1".

Non Plug-in Type: Grommet, Grommet Terminal, Conduit Terminal, DIN Terminal

- Wiring for every valve



VV5FR2 - 10 - 05 1 - 01

Series VFR2000 Manifold
Non plug-in type

Stations

02	2 stations
⋮	⋮
15	15 stations

Symbol			Port size			Thread type		
Symbol	Passage		Porting specifications A, B	Symbol	P, EA, EB	A, B *	Nil	Rc
	P	EA, EB						
01				01		1/8	F	G
02				02		1/4	N	NPT
1	Common	Common	Side	C6	1/4	One-touch fitting for ø6	T	NPTF
2 *			Bottom					
3 *	Side							
4 *	Bottom							
5 *	Individual	Common	Side	C8		One-touch fitting for ø8		
6 *			Bottom					
7 *	Individual	Individual	Side	M		Mixed		
8 *			Bottom					

* For bottom ported, 1/8 is only available.

* Option

Note) P port or EA/EB port of symbol "3" to "8" can be individual port with block plate. Therefore, if using individual SUP spacer or individual EXH spacer for individual port, its symbol is "1".


5 Port Pilot Operated Solenoid Valve Rubber Seal, Plug-in/Non Plug-in Series VFR2000

Manifold/Option Parts Assembly

Individual SUP spacer

Setting individual SUP spacer on the manifold block enables individual SUP port for each valve.


Body type	Plug-in type	Non plug-in type
Part no. Rc 1/8	VVFS2000-P-01-1	VVFS2000-P-01-2
Rc 1/4	VVFS2000-P-02-1	VVFS2000-P-02-2



Individual EXH spacer

Setting individual EXH spacer on the manifold block enables individual EXH port for each valve.

Body type	Plug-in type	Non plug-in type
Part no. Rc 1/8	VVFS2000-R-01-1	VVFS2000-R-01-2
Rc 1/4	VVFS2000-R-02-1	VVFS2000-R-02-2



SUP block disk

When supplying manifold with more than two different kinds of pressure, high and low, insert a block disk in between stations subjected to different pressures.

Body type	Plug-in type	Non plug-in type
Part no.	AXT625-12A	

EXH block disk

When valve exhaust affects the other stations in the circuit, insert EXH block disk in between stations to separate valve exhaust.


Body type	Plug-in type	Non plug-in type
Part no.	AXT625-12A	



Throttle valve spacer

Needle valve set on the manifold block can control cylinder speed by throttling exhaust.


Body type	Plug-in type	Non plug-in type
Part no.	VVFS2000-20A-1	VVFS2000-20A-2



Interface regulator

Interface regulator set on the manifold block can regulate pressure for each valve. (Refer to "Flow Characteristics" on page 3-5-6 before operation.)

Body type	Plug-in type	Non plug-in type
P port regulation	ARBF2000-00-P-1	ARBF2000-00-P-2




Air release valve spacer

Valve VFR21□0 (single) can be used as air release valve by combining with release valve spacer.

Body type	Plug-in type	Non plug-in type
Part no.	VVFS2000-24A-1 ^h	VVFS2000-24A-2 ^h

Note) L: U side mount R: D side mount



SUP stop valve spacer ^{Note)}

If SUP stop valve spacer is set, valve can be removed for maintenance without stopping air pressure supply for other valves.

Body type	Plug-in type	Non plug-in type
Part no.	VVFS2000-37A-1	VVFS2000-37A-2

(Height will be 23.2 mm higher.)

Note) Used with manifold base. Please contact SMC for details.

Blanking plate


It is used by attaching on the manifold block for being prepared for removing a valve for maintenance reasons or planning to mount a spare valve, etc.

Body type	Plug-in type	Non plug-in type
Part no.	VVFS2000-10A	

Manifold Option

With control unit Plug-in/Non Plug-in type


- Filter, regulation valve, pressure switch and air release valve all combine to form one unit.
- Piping processes are eliminated.



For details, refer to page 3-5-24.

With serial interface unit for serial transmission Plug-in type

- Solenoid valve wiring process reduced considerably.
- Disperse installation possible. Manifold solenoid valve: 8 stations max, 32 positions (512 solenoids).
- Maintenance and inspection are easy.



For details, refer to "Serial Transmission" catalog separately.

VK

VZ

VF

VFR

VP4

VZS

VFS

VS4

VQ7


EVS

VFN


Series VFR2000

Manifold Plug-in type

With terminal block (Individual junction cover): VV5FR2-01T-Station 1-Port size



With terminal block (One-piece junction cover): VV5FR2-01T1-Station 1-Port size




n: Stations

Stations	1	2	3	4	5	6	7	8	9	10	Formula
L ₁	75	103	131	159	187	215	243	271	299	327	L ₁ = 28 x n + 47
L ₂	84	112	140	168	196	224	252	280	308	336	L ₂ = 28 x n + 56

5 Port Pilot Operated Solenoid Valve Rubber Seal, Plug-in/Non Plug-in Series VFR2000


Manifold Plug-in type

With multi-connector: VV5FR2-01CD1-Station 1-Port size, VV5FR2-01CU1-Station 1-Port size



- VK
- VZ
- VF
- VFR**
- VP4
- VZS
- VFS
- VS4
- VQ7
- EVS
- VFN

With D-sub connector: VV5FR2-01FD1-Station 1-Port size, VV5FR2-01FU1-Station 1-Port size




Stations	1	2	3	4	5	6	7	8	Formula
L ₁	75	103	131	159	187	215	243	271	L ₁ = 28 x n + 47
L ₂	84	112	140	168	196	224	252	280	L ₂ = 28 x n + 56


5 Port Pilot Operated Solenoid Valve Rubber Seal, Plug-in/Non Plug-in Series VFR2000

Manifold/Option Parts Assembly Plug-in type/Non plug-in type


Individual SUP spacer:
 VVFS2000-P-⁰¹/₀₂-1 (Plug-in type)
 VVFS2000-P-⁰¹/₀₂-2 (Non plug-in type)




Throttle valve spacer:
 VVFS2000-20A-1 (Plug-in type)
 VVFS2000-20A-2 (Non plug-in type)




Individual EXH spacer:
 VVFS2000-R-⁰¹/₀₂-1 (Plug-in type)
 VVFS2000-R-⁰¹/₀₂-2 (Non plug-in type)




Interface regulator
 ARBF2000-00-P-1 (Plug-in type)
 ARBF2000-00-P-2 (Non plug-in type)



SUP block disk: AXT625-12A
EXH block disk: AXT625-12A



Release valve spacer
 VVFS2000-24A-1^R/_L (Plug-in type)
 VVFS2000-24A-2^R/_L (Non plug-in type)



Note) VVFS2000-24A-1/2R (D side mounting)

- VK
- VZ
- VF
- VFR
- VP4
- VZS
- VFS
- VS4
- VQ7
- EVS
- VFN


Series VFR2000

Manifold with Control Unit

- Control unit (Filter, Regulator, Pressure switch, Air release valve) are all standardized to the one unit, and can be mounted on the manifold base without any attachments.
- Piping processes are eliminated.



Plug-in type



Non plug-in type

⚠ Caution

Air filter with auto-drain or manual drain must be mounted with the air filter at the bottom.

Manifold Specifications

Manifold	Plug-in type: VV5FR2-01□	Non plug-in type: VV5FR2-10
Wiring	With terminal block With multi-connector With D-sub connector	Grommet, Grommet terminal Conduit terminal, DIN terminal L plug connector, M plug connector
Applicable valve model	VFR2□00-□F	VFR2□10-□G, VFR2□10-□E VFR2□10-□T, VFR2□10-□DY VFR2□10-□L, VFR2□10-□M
Porting specifications Rc	Common SUP, Common EXH	
	A, B port	Side: Rc 1/8, 1/4, C6, C8, Bottom: Rc 1/8 (Option)
	P, EA, EB port	Side: Rc 1/4, Bottom: Rc 1/8 (Option)
Stations	2 to 15 stations * (With multi-connector/D-sub connector: 2 to 8 stations)	



* Including station of control unit

Control Unit Specifications

Air filter (With auto-drain/With manual drain)	
Filtration degree	5 μm
Regulator	
Set pressure (Outlet pressure)	0.05 to 0.85 MPa
Pressure switch	
Set pressure range: OFF	0.1 to 0.6 MPa
Differential	0.08 MPa
Contact	1a
Indicator light	LED (RED)
Max. switch capacity	2 VA AC, 2 W DC
Max. operating current	24 VAC, DC or less: 50 mA 100 VAC, DC: 20 mA
Inside voltage drop	4 V or less
Air release valve (Single only)	
Operating pressure range	0.2 to 0.9 MPa

Control Unit/Option

Air release valve spacer ⁽¹⁾	<Plug-in type>	
	VVFS2000-24A-1R (D side mounting) VVFS2000-24A-1L (U side mounting)	
Pressure switch ⁽²⁾	<Non plug-in type>	
	VVFS2000-24A-2R (D side mounting) VVFS2000-24A-2L (U side mounting)	
Pressure switch	IS1000P-2-1	
Blanking plate	For filter regulator	MP2-2
	For pressure switch	MP3-2
	For air release valve	AXT625-18A
Filter element	111511-5B	



Note 1) Refer to "Manifold Option" on page 3-5-23.

Note 2) Pressure switch cannot be mounted later on non plug-in type.

5 Port Pilot Operated Solenoid Valve Rubber Seal, Plug-in/Non Plug-in Series VFR2000

How to Order

VV5FR2 — **10** — **08** **1** — **01** — **AP** — **1**

Series VFR2000 Manifold

Base model

Symbol	Electrical entry	Connector mounting direction	Junction cover
01T	Plug-in type terminal block	—	Stacking type
01T1			Integrated type
01CD1	Plug-in type multi-connector	D side	Integrated type
01CU1		U side	
01FD1	Plug-in type D-sub connector	D side	Integrated type
01FU1		U side	
10	Non plug-in type	—	—

Stations

02	2 stations
⋮	⋮
15 (Note)	15 stations

Note) • 01CD1, 01CU1, 01FD1, 01FU1: Max. 8 stations
• 01T, 01T1, 10: Max. 15 stations
• Including station of control unit

Symbol

Symbol	Passage		Porting specifications (A, B)
	P	EA, EB	
1	Common	Common	Side
2*			Bottom
3*	Common	Individual	Side
4*			Bottom
5*	Individual	Common	Side
6*			Bottom
7*	Individual	Individual	Side
8*			Bottom

* Option
P port or EA/EB port of symbol "3" to "8" can be individual port with block disk. Therefore, if using individual SUP spacer or individual EXH spacer for individual port, its symbol is "1".

Air release valve coil rating

Nil	None
1	100 VAC, 50/60 Hz
5	24 VDC
9	Other

Control unit type

Symbol	Nil	MP	AP	M	A	G	F	C	E
Control equipment									
Air release valve		●	●	●	●			●	●
Air filter regulator with manual drain		●		●		●			
Air filter regulator with auto-drain			●		●		●		
Pressure switch		●	●						
Blanking plate (Air release valve)						●	●		
Blanking plate (Filter regulator)								●	
Blanking plate (Pressure switch)				●	●	●	●	●	
Required stations	2 stations								1 station

Note) Control unit is D side mounting only.

Thread type

Nil	Rc
F	G
N	NPT
T	NPTF

Port size

Symbol	P, EA, EB	A, B
01	1/4	1/8
02		1/4
C6		One-touch fitting for ø6
C8		One-touch fitting for ø8
M		Mixed

- VK
- VZ
- VF
- VFR
- VP4
- VZS
- VFS
- VS4
- VQ7
- EVS
- VFN

How to Order Manifold Assembly

<Example> Plug-in type with terminal block

VV5FR2-01T1-091-02-MP5..... 1 set (Manifold base part no.)
 *VFR2100-5FZ..... 5 sets (2 position single part no.)
 *VFR2200-5FZ..... 2 sets (2 position double part no.)
 ↳ The asterisk denotes the symbol for assembly. Prefix it to the part nos. of the solenoid valve, etc.

The 1st and 2nd station are used for control unit mounting.
 When ordering, specify the part nos. in order from the 3rd. station in the D side.
 When entry of part numbers becomes complicated, indicate on the manifold specification sheet.

<Example> Non plug-in type

VV5FR2-10-071-01-M5..... 1 set (Manifold base part no.)
 *VFR2110-5D..... 5 sets (2 position single part no.)
 ↳ The asterisk denotes the symbol for assembly. Prefix it to the part nos. of the solenoid valve, etc.


The 1st and 2nd station are used for control unit mounting.
 When ordering, specify the part nos. in order from the 3rd. station in the D side.
 When entry of part numbers becomes complicated, indicate on the manifold specification sheet.

Series VFR2000


Manifold with Control Unit Plug-in type/Non plug-in type

Plug-in type:

VV5FR2-01T- Station 1- Port size- Control unit- Voltage of air release valve




Example for manifold




Non plug-in type:

VV5FR2-10- Station 1- Port size- Control unit- Voltage of air release valve




Example for manifold



	n: Stations									
Stations	3	4	5	6	7	8	9	10	Formula	
L ₁	131	159	187	215	243	271	299	327	L ₁ = 28 x n + 47	
L ₂	140	168	196	224	252	280	308	336	L ₂ = 28 x n + 56	
L ₃ (MP)	278	306	334	362	390	418	446	474	L ₃ = 28 x n + 194	
L ₃ (AP)	319.5	347.5	375.5	403.5	431.5	459.5	487.5	515.5	L ₃ = 28 x n + 235.5	

5 Port Pilot Operated Solenoid Valve Rubber Seal, Plug-in/Non Plug-in Series VFR2000

Manifold Base Construction Plug-in type/Non plug-in type



- VK
- VZ
- VF
- VFR
- VP4
- VZS
- VFS
- VS4
- VQ7
- EVS
- VFN

Replacement Parts

No.	Description	Material	Part no.
①	Connection fitting A	Steel plate	AXT625-4-1
②	Connection fitting B	Steel plate	AXT625-5
③	Gasket A	NBR	AXT625-17
④	Gasket B	NBR	AXT625-16
⑤	O-ring	NBR	18 x 15 x 1.5
⑥	O-ring	NBR	10.5 x 7.5 x 1.5
⑦	O-ring	NBR	8 x 5 x 1.5
⑧	Adapter plate assembly	—	For 01T For 01T1 AXT625-28-1A (Terminal and adapter plate)
	Adapter plate	Resin	For 01C For 01F For 01SU AXT625-28-1 VVF2000-26-6 AXT625-6

No.	Description	Material	Part no.
⑨	Junction cover assembly	—	For 01T AXT625-28-3A
			For 01T1 AXT625-28-7A- ^[Stations]
			For 01C AXT625-28-7A- ^[Stations]
			For 01F VVF2000-26-5A- ^[Stations]
⑬	Rubber plug	NBR	For 01T For 01SU AXT623-22

Replacement Parts: Sub Assembly



Note) Manifold Base/Construction: Plug-in type with terminal block.

No.	Description	Assembly part no.	Component parts	Applicable manifold base
⑩	Manifold block assembly (1)	AXT625-20A- $\frac{1}{2}$ CS (2)	Manifold block ⑩, Metal joint ①, ②, O-ring ⑤, ⑥, ⑦ Terminal ⑧, Junction cover ⑨, Adaptor plate, Pin housing, Guide	Plug-in type
		AXT625-10A- $\frac{1}{2}$ CS (3)	Manifold block ⑩, Metal joint ①, ②, O-ring ⑤, ⑥, ⑦	Non plug-in type
⑪	End plate (U side) assembly	AXT625-2A-20	End plate (U) ⑪, Metal joint ①, ②, Gasket A ③, Guard ⑬	Plug-in type (For 01T) (3) With terminal block (01T1)
		AXT625-2A-10	End plate (U) ⑪, Metal joint ①, ②, Gasket A ③, Guard ⑬	Non plug-in type (For 10) (3)
⑫	End plate (D side) assembly	AXT625-3A-20	End plate (D) ⑫, Metal joint ①, ②, Gasket B ④, Guard ⑬, Steel ball	Plug-in type (For 01T) (3) With terminal block (01T1)
		AXT625-3A-10	End plate (D) ⑫, Metal joint ①, ②, Gasket B ④, Guard ⑬, Steel ball	Non plug-in type (For 10) (3)



Note 1) For side ported

Note 2) 1: A, B port size Rc 1/8, 2: A, B port size Rc 1/4

Note 3) Please contact SMC if parts except for 10/01T/01T1 are needed.